



HOW TO PREPARE PERFECT COFFEE

CAUTION:

- Do not immerse the base in water.
- Do not plug in the unit without water or coffee in the urn.
- Use **only** with 110–120 Volt AC power. Do **not** use with 220 Volt or DC power.
- Fill with fresh, cold tap water to the desired cup level.
- Do not use hot water to brew coffee.

IMPORTANT:

This unit draws 18 AMPS. Do not use it on the same circuit with other electrical appliances.

Plug directly into a wall outlet—**do not** use an extension cord, as this may cause the unit to malfunction.

INSTRUCTIONS:

1. Wet the bottom of the coffee basket, then add drip grind or regular grind coffee according to the chart below.
2. Plug the cord into an AC outlet and turn the switch to “**ON.**”
3. When the signal light flashes, the coffee is ready to serve.
4. The unit will automatically switch to low heat to keep the coffee at the proper serving temperature.

Coffee Amounts:

- 55-cup maker → ½ lb. coffee
- 90-cup maker → 1 lb. coffee

Coffee strength can be adjusted by adding or reducing the recommended amount of coffee.

Brewing time is approximately 30 minutes for a 55-cup maker and 45 to 55 minutes for a 90-cup maker.